

Parameters Added to the DD-500

Added PATCH Parameters

The following parameters have been added when MODE=VINTAGE DIGITAL and TYPE=SDE-3000 or SDE-2000.

| Parameter | Value | Explanation |
|----------------|----------|---|
| DELAY PHASE | NOR, INV | Specifies the phase of the delay sound. Selecting INV inverts the phase. |
| FEEDBACK PHASE | NOR, INV | Specifies the phase of the delay sound feedback. Selecting INV inverts the phase. |

The following parameter has been added when MODE=TAPE and TYPE=RE-201.

| Parameter | Value | Explanation |
|-----------|-------------------------------------|---|
| TAPE HEAD | 1, 2, 3, 1+2, 1+3, 2+3, 1+2+3 | Selects the playback head(s) to use. Playback heads 2/3 provide delay times that are two times or three times as long as playback head 1. |

Added MIDI Parameters

| Parameter | Value | Explanation |
|--------------|----------|--|
| BANK SEL OUT | MSB, M+L | Specifies the bank select message that is transmitted simultaneously with the program change. If you select MSB, only MSB (CC#0) is transmitted. If you select M+L, both MSB and LSB (CC#32) are transmitted. |

* Bank select messages are not transmitted unless PC OUT is ON.



DD-500追加パラメーター

PATCH 追加パラメーター

MODE=VINTAGE DIGITAL、TYPE=SDE-3000、SDE-2000 のとき、以下のパラメーターが追加されます。

| パラメーター | 値 | 説明 |
|----------------|---------|--|
| DELAY PHASE | NOR、INV | ディレイ音の位相を設定します。INV を選ぶと位相が反転します。 |
| FEEDBACK PHASE | NOR、INV | ディレイ音のフィードバックの位相を設定します。INV を選ぶと位相が反転します。 |

MODE=TAPE、TYPE=RE-201 のとき、以下のパラメーターが追加されます。

| パラメーター | 値 | 説明 |
|-----------|---------------------------------|--|
| TAPE HEAD | 1、2、3、 1+2、1+3、 2+3、1+2+3 | 使用する再生ヘッドを選択します。再生ヘッド 2 / 3 は再生ヘッド 1 の 2 倍 / 3 倍のディレイタイムになります。 |

MIDI 追加パラメーター

| パラメーター | 値 | 説明 |
|--------------|---------|---|
| BANK SEL OUT | MSB、M+L | プログラム・チェンジと同時に送信するバンクセレクト・メッセージを設定します。 MSB を選ぶと MSB (CC#0) だけが、M+L を選ぶと MSB と LSB (CC#32) が送信されます。 |

※ PC OUT が ON になっていないとバンクセレクト・メッセージは送信しません。