



**GUITAR EFFECTS  
PROCESSOR**

**GT-1000**

SoundList



# Sound List

## Preset Patch List

Patch #	Patch name	CTL1	CTL2	CTL3	EXP1 SW	EXP1
P01-1	PREMIUM DRIVE	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P01-2	DEEP SHIMMER REV	DISTORTION1 AIRD PREAMP1 AIRD PREAMP2	DISTORTION1 SOLO AIRD PREAMP1 SOLO	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P01-3	THE POWER OF MDP	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P01-4	MODERN LD-CL	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P01-5	MULTIBAND CRUNCH	COMPRESSOR	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P02-1	3D JAZZ CHORUS	FX1 (CLASSIC VIBE) FX3 (VIBRATO)	CHORUS FX2 (CHORUS)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P02-2	FUZZ LEAD	REVERB	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P02-3	RECT 57 SL PN TW	FX1 (PAN) FX3 (SLICER)	MASTER DELAY TWIST TRIGGER	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P02-4	COUNTRY TWANG	DISTORTION1	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P02-5	GUITAR PAD 01	TERA ECHO TRIGGER	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P03-1	ROTATOR	FX2 (ROTARY) SPEED SELECT	REVERB	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P03-2	CLEAN & AG MIX	CHORUS	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P03-3	BURNING PURPLE	DISTORTION1	CHORUS	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P03-4	PHAT GAINER	AIRD PREAMP1 SOLO AIRD PREAMP2 SOLO	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P03-5	MILD ORGAN SPACE	DIV1 CH.SELECT CHORUS	FX1 (ROTARY) DELAY4	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P04-1	DIAMOND/CRUNCH	DIV1 CH.SELECT	DISTORTION2 DISTORTION1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P04-2	PEDAL POWER	FX1 (S-BEND) TRIGGER	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P04-3	PATTERN DELAY X	DELAY1	DELAY2	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P04-4	SINGLE COIL AC	DISTORTION2 FX2 (AC GTR SIM) EQ2	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P04-5	CRYSTAL CLOUDS	CHORUS	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P05-1	TREMOLO REVERB	DISTORTION1	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P05-2	JAZZ HOLLOW	AIRD PREAMP2 SOLO	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P05-3	DRY X-DRIVE	DISTORTION1	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P05-4	BASS+GUITAR MIX	DISTORTION1 DIV3 CH.SELECT	MASTER DELAY CHORUS DELAY1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P05-5	FOOT VOL DRV CTL	DIV1 CH.SELECT DIV2 CH.SELECT	DELAY1 MIXER3 CH.A/B BALANCE	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P06-1	SIMPLE TWEED 87	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX

Patch #	Patch name	CTL1	CTL2	CTL3	EXP1 SW	EXP1
P06-2	DOUBLE AMP	DIV2 CH.SELECT	DISTORTION1 MIXER1 MODE MASTER DELAY DISTORTION2	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P06-3	CLEAN CHO/DLY	FX1 (CHORUS)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P06-4	12 STRUNG	FX3 (OVERTONE)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P06-5	SHRED LEAD	FX1 (PHASER)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P07-1	CRUNCHED	DISTORTION1	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P07-2	CTL2:WARP LEAD	DIV1 CH.SELECT	WARP TRIGGER	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P07-3	JUGGER FLAT LD	DIV1 CH.SELECT	FX1 (S-BEND) TRIGGER	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P07-4	BRIT ROCK 1978	DIV2 CH.SELECT	FX1 (PHASER)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P07-5	CLEAN COMBO	FX1 (VIBRATO)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P08-1	DRIVEN DELUXE	FX3 (TREMOLO)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P08-2	MS CLEAN	DIV1 CH.SELECT DIV2 CH.SELECT	DELAY1 DELAY2	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P08-3	RICH ACOUSTIC	CHORUS	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P08-4	TWO SPEED TREM	FX1 (TREMOLO) RATE	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P08-5	BOOSTED X	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P09-1	OCTFUZZ LEAD	REVERB	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P09-2	EXPERIENCE BLUES	FX1 (CLASSIC VIBE)	REVERB	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P09-3	BRITISH CRUNCH	FX3 (TREMOLO)	AIRD PREAMP1 GAIN SW AIRD PREAMP1 LEVEL	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P09-4	FUNKY RHYTHM	DISTORTION1 FX1 (TOUCH WAH) FREQUENCY FX2 (OVERTONE)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P09-5	LOW AND DIRTY	FX2 (PHASER)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P10-1	WAH SOLO	REVERB	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P10-2	FUSION LEAD	FX1 (CHORUS)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P10-3	OVERTONES	FX1 (OVERTONE)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P10-4	MONO SYNTH LEAD	FX2 (FLANGER)	FX1 (FEEDBACKER) TRIGGER	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P10-5	STRAY CUTZ	DISTORTION1	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P11-1	CRUNCH VIB/CE-1	DIV1 CH.SELECT	MASTER DELAY WARP TRIGGER FX3 (VIBRATO) TRIGGER	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P11-2	MAXIMUM 451 BEND	DIV1 CH.SELECT	FX1 (S-BEND) TRIGGER	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P11-3	MELLOW JAZZ CLN	DIV1 CH.SELECT	AIRD PREAMP1 SOLO AIRD PREAMP2 SOLO	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P11-4	JC-120 OCT FUZZ	DIV1 CH.SELECT	EQ3	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P11-5	BRIT STACK 57	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P12-1	VINTAGE FLOYD	FX2 (ROTARY) SPEED SELECT	DELAY2	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P12-2	BRIT WALL	AIRD RPEAMP1 SOLO	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P12-3	WILD STEREO	BPM TAP	MASTER DELAY	TUNER	CHORUS	MASTER DELAY EFFECT LEVEL
P12-4	SPRINGY BLUES	DISTORTION1	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX

## Sound List

Patch #	Patch name	CTL1	CTL2	CTL3	EXP1 SW	EXP1
P12-5	VINTAGE VIBE	DISTORTION1	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P13-1	GIG READY	DIV1 CH.SELECT	MASTER DELAY	TUNER	AIRD PREAMP2 SOLO	AIRD PREAMP2 GAIN
P13-2	GREEN STEW	FX1 (PHASER)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P13-3	EDGY DELAY	BPM TAP	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P13-4	EMPRESS MAY	MASTER DELAY	MASTER DELAY TAP	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P13-5	DELUXE CRUNCH	DIV1 CH.SELECT	COMPRESSOR DISTORTION2	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P14-1	DEFRETTER	DIV1 CH.SELECT	FX3 (VIBRATO) TRIGGER	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P14-2	STEREO TREMOLO	FX3 (S-BEND) TRIGGER	FX1 (TREMOLO) TRIGGER FX2 (TREMOLO) TRIGGER	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P14-3	FLYING WAH	MASTER DELAY	BPM TAP	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P14-4	JAZZ OF TODAY	DIV1 CH.SELECT	DELAY1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P14-5	BLUES GUITAR TX	DISTORTION1	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P15-1	SHOEGAZER	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P15-2	OVERTONE LEAD	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P15-3	PRE REVERB RETRO	DIV1 CH.SELECT	FX1 (TREMOLO)	TUNER	EQ2	EQ2 LOW CUT EQ2 HIGH CUT
P15-4	LATE 60s > VIB	FX2 (CLASSIC VIBE)	MASTER DELAY	TUNER	FX2 (CLASSIC VIBE)	FX2 (CLASSIC VIBE) RATE
P15-5	STEP PHASER	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P16-1	ORGANISH DELAY	DIV1 CH.SELECT	FX1 (PHASER) FX2 (ROTARY)	TUNER	FX2 (ROTARY)	FX2 (ROTARY) SPEED SELECT
P16-2	SG PAN CTL2:BPM	FX3 (PAN)	BPM TAP	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P16-3	DOUBLE X-DRIVE	DIV1 CH.SELECT	DISTORTION1 DISTORTION2	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P16-4	FILTERED DELAY	DIV1 CH.SELECT	BPM TAP	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P16-5	MULTIPLE EFFECTS	DIV1 CH.SELECT DIV3 CH.SELECT	MASTER DELAY COMPRESSOR FX1 (OCTAVE) CHORUS DISTORTION2 EQ3 FX2 (OCTAVE) FX3 (CHORUS) DELAY3 DELAY4	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P17-1	CTL1:DIMINISH DL	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P17-2	PSHIFT DELAY	DIV1 MODE	DELAY2	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P17-3	SITAR+AG STEREO	DIV2 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P17-4	TRADITIONAL RT	DIV1 CH.SELECT	FX2 (ROTARY) SPEED SELECT	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P17-5	PROG METAL	DIV1 CH.SELECT	DIV2 CH.SELECT AIRD PREAMP1 TYPE AIRD PREAMP1 GAIN	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX

Patch #	Patch name	CTL1	CTL2	CTL3	EXP1 SW	EXP1
P18-1	AMBIENT SWELL	COMPRESSOR	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P18-2	TR SPEED CHANGES	DIV1 CH.SELECT	FX1 (S-BEND) TRIGGER	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P18-3	BUTTERSMOOTH LD	DISTORTION1	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P18-4	CEE CEE TOP 4 LP	DISTORTION1	AIRD PREAMP1 SOLO AIRD PREAMP2 SOLO	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P18-5	SCRIPT PHASED MS	FX1 (PHASER)	DELAY2	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P19-1	COLD SHOOTING>ST	FX1 (VIBRATO) FX2 (ROTARY)	REVERB EFFECT LEVEL	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P19-2	AC GTR'S LOVE IT	FX2 (CHORUS)	DELAY1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P19-3	BRIDGE OF S.	DIV1 CH.SELECT	DISTORTION1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P19-4	DreaenoughtSlide	REVERB	DELAY1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P19-5	VH ON STEROIDS	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P20-1	LEZLY VIBES	FX1 (CLASSIC VIBE) FX2 (ROTARY)	DELAY1 DELAY2	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P20-2	OMNISPHERICAL	CHORUS	DELAY1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P20-3	RINGMOD BASS	FX2 (OCTAVE)	FX1 (RING MOD) FX3 (RING MOD)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P20-4	FRETLESS GUITAR	FX1 (SLOW GEAR)	FX2 (DEFRETTER) FX3 (DEFRETTER)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P20-5	MEAN CLEAN	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P21-1	SLICE AND DICE	FX1 (SLICER) FX3 (SLICER)	BPM TAP	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P21-2	OCTFUZZ>NECK PU	FX3 (CLASSIC VIBE) FX2 (FLANGER)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P21-3	HEAVY PARKING	CHORUS	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P21-4	CLEAN + PAD	AIRD PREAMP2 SOLO AIRD PREAMP1	FX1 (PITCH SHIFT) PS2 LEVEL	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P21-5	X-HI GAIN LEAD	CHORUS	DISTORTION1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P22-1	DRIVE + BASS	CHORUS	FX1 (OCTAVE) POLY OCTAVE LEVEL	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P22-2	PRIME SHIMMER	DISTORTION1	FX2 (PITCH SHIFT) PS2 LEVEL	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P22-3	TERA SHIMMER	DISTORTION1	TERA ECHO FEEDBACK	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P22-4	FLANGER REVERB	DIV1 CH.SELECT	CHORUS	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P22-5	PANNING DELAY	DIV1 CH.SELECT	EQ3	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P23-1	DRIVE + ORGAN	DISTORTION2 FX2 (AC GTR SIM) EQ2	DELAY1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P23-2	PRIME X-CRUNCH	DIV1 CH.SELECT	DELAY1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P23-3	HEAVY X-METAL	FX1 (OCTAVE)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P23-4	+1OCT CHORUS	DIV1 CH.SELECT	FX3 (PHASER)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P23-5	CLEAN + DRIVE	DIV2 CH.SELECT DIV3 CH.SELECT	FX1 (PHASER)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P24-1	SUPER OCTAVE	DISTORTION1	FX1 (PITCH SHIFT) PS1 FEEDBACK	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P24-2	TIGHT ECHO LEAD	EQ3	FX1 (TREMOLO)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX

## Sound List

Patch #	Patch name	CTL1	CTL2	CTL3	EXP1 SW	EXP1
P24-3	DIST + CLEAN REV	DELAY3	FX2 (CHORUS)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P24-4	CRYSTAL CLEAN	DIV1 CH.SELECT	FX1 (PHASER)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P24-5	PANNING PHASE	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P25-1	DEEP PAD ECHO	DISTORTION1	AIRD PREAMP1 SOLO	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P25-2	FAST MOD PHASE	CHORUS	DELAY1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P25-3	VIBRATREMOLO	MASTER DELAY	CHORUS	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P25-4	LIGHT CHORUS LD	COMPRESSOR	FX1 (SLOW GEAR)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P25-5	RINGMOD BELL	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P26-1	FOR NYLON STRING	CHORUS	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P26-2	GROOVY FUNK	FX1 (PHASER)	CHORUS	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P26-3	THINLINE JAZZ	DIV1 CH.SELECT	CHORUS	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P26-4	ACO/DRIVE MIX	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P26-5	LEAD DELAY	DIV1 CH.SELECT	DISTORTION2 MIXER2 CH.A/B BALANCE MIXER3 CH.A/B BALANCE	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX DELAY4 DIRECT LEVEL
P27-1	DELAYED CLEAN	DIV1 CH.SELECT DIV3 CH.SELECT	MASTER DELAY DELAY1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P27-2	DELAYED FLANGER	DIV1 CH.SELECT DIV3 CH.SELECT	DELAY2 FX3 (FLANGER) MIXER2 CH.A/B BALANCE	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P27-3	HI-GAIN JC	DIV1 CH.SELECT DIV2 CH.SELECT	DELAY1 DELAY2	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P27-4	4-STEP CRUNCH	DIV1 CH.SELECT DIV2 CH.SELECT	EQ3	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P27-5	FRETLESS BALLAD	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P28-1	FUZZY RING MOD	DIV1 CH.SELECT DIV3 CH.SELECT	MASTER DELAY DELAY1 DELAY2	TUNER	FX1 (OVERTONE)	FX3 (RING MOD) FREQUENCY
P28-2	SITAR FANTASY	DIV1 CH.SELECT DIV3 CH.SELECT	MASTER DELAY DELAY1 DELAY2	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P28-3	BASS HOLD:CTL1	FX2 (SOUND HOLD) TRIGGER MIXER3 CH.A/B BALANCE	MASTER DELAY CHORUS	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P28-4	PULSE WAVE	DIV2 CH.SELECT DIV3 CH.SELECT	BPM TAP	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P28-5	STEP FUZZ	DIV1 CH.SELECT	BPM TAP	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P29-1	COMP DRIVE	DIV1 CH.SELECT DIV2 CH.SELECT	MASTER DELAY DELAY1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P29-2	SLICE+EXP FILTER	DISTORTION2 DISTORTION 1 FX2 TYPE	BPM TAP	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX

Patch #	Patch name	CTL1	CTL2	CTL3	EXP1 SW	EXP1
P29-3	CLEAN<->LEAD VARI	DIV1 CH.SELECT	DIV2 CH.SELECT DIV3 CH.SELECT	TUNER	DISTORTION2 DISTORTION1	FOOT VOLUME PEDAL FX DIRECT MIX
P29-4	EXP OUTER SPACE	DISTORTION1 DISTORTION2	BPM TAP	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX FX1 (RING MOD) FREQUENCY FX2 (RING MOD) FREQUENCY FX3 (RING MOD) FREQUENCY
P29-5	DEAD OR ALIVE	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P30-1	JAZZ FUNK CHORUS	DIV1 CH.SELECT	CHORUS	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P30-2	NEW CHAPTER JAZZ	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P30-3	VELVET LEAD	DISTORTION2	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P30-4	PEDAL SEARING LD	DELAY1	DISTORTION1	TUNER	PEDAL FX FX1 (RING MOD)	PEDAL FX FX1 (RING MOD) FREQUENCY FX1 (RING MOD) FREQ MOD DEPTH
P30-5	BITING STACK LD	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P31-1	DUAL TONALITY	FX1 (VIBRATO)	REVERB	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P31-2	OVERTONAL DRIVE	DISTORTION1	FX1 (OCTAVE)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P31-3	WEST COAST OD	FX1 (PHASER)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P31-4	ST CORE METAL	FX1 (CLASSIC VIBE)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P31-5	JC+DIST+DLY=YEAH	DISTORTION1	DELAY1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P32-1	MIXTURE ROCK MOD	DISTORTION2	FX1 (AUTO WAH)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P32-2	STEREO X	COMPRESSOR	DELAY1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P32-3	INFINITE THING	DELAY3	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P32-4	BRITIFIER	DIV1 MODE AIRD PREAMP1 LEVEL	AIRD PREAMP1 SOLO AIRD PREAMP2 SOLO	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P32-5	CRESCENT DELAY	DISTORTION2	COMPRESSOR	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P33-1	FLEXIBLE RIG	DELAY1	CHORUS DISTORTION1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P33-2	DJENTY CORE	FX1 (COMPRESSOR)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P33-3	CLASSIC METAL	DISTORTION1 SOLO	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P33-4	TWIN CRIMSON LD	FX1 (HARMONIST)	DELAY1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P33-5	PLEXI CRUNCH	AIRD PREAMP 1 SOLO	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P34-1	PLEXI SOLO	DISTORTION 1	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P34-2	ROTARY PHAZE	FX3 (ROTARY)	FX1 (PHASER)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P34-3	SUPER SLICER	FX3 (OCTAVE)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P34-4	FAT FLANGER	FX1 (FLANGER)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P34-5	AC RESO STANDARD	MASTER DELAY AIRD PREAMP 1 SOLO	CHORUS	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P35-1	RETRO RING SEQ	FX3 (SLICER)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P35-2	7TH WONDER	FX2 (HARMONIST) HR1 HARMONY FX3 (HARMONIST) HR2 HARMONY	FX1 (FEEDBACKER) TRIGGER	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P35-3	MOVING CHORDS	REVERB	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P35-4	JC-120 FLAT	DIV1 CH.SELECT	DISTORTION1 EQ1 HIGH CUT	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX

## Sound List

Patch #	Patch name	CTL1	CTL2	CTL3	EXP1 SW	EXP1
P35-5	BOUTIQUE 87 PH	DIV1 CH.SELECT	FX1 (PHASER) DELAY1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P36-1	X-MOD 451 OT	FX2 (OVERTONE) MASTER DELAY DELAY1	FX1 (FEEDBACKER) TRIGGER	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P36-2	TWIN ST FLAT PH	DISTORTION1 EQ2	DELAY2 DELAY3 FX2 (PHASER) CHORUS MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P36-3	DIAMOND 421 DLY	DIV1 CH.SELECT	FX1 (CLASSIC VIBE) DELAY4	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P36-4	SYNTH S-BEND RES	DIV1 CH.SELECT	FX2 (S-BEND) TRIGGER	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P36-5	JUGGERNAUT FLAT	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P37-1	NATURAL 451 TERA	DIV1 CH.SELECT	REVERB	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P37-2	X-CRUNCH 57 TR	DIV1 CH.SELECT	FX1 (TREMOLO)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P37-3	SUPREME 421 OVER	DIV1 CH.SELECT	FX1 (OVERTONE)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P37-4	S-BEND DRIVE LD	FX2 (FEEDBACKER) TRIGGER	FX3 (S-BEND) TRIGGER	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P37-5	DELUXE 57 FZ	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P38-1	SOULFUL CLEAN	DISTORTION1	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P38-2	AUSSIE ROCK	AIRD PREAMP1 SOLO	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P38-3	SWAMPY BAYOU	FX1 (TREMOLO)	FX3 (TREMOLO)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P38-4	STAR SPANGLED	DISTORTION1	REVERB	TUNER	FX1 (CLASSIC VIBE)	FX1 (CLASSIC VIBE) RATE
P38-5	ARLINGTON COWBOY	CHORUS	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P39-1	DJENTLEMAN	DIV1 CH.SELECT DIV2 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P39-2	LOFI BLUES	DISTORTION1	DELAY1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P39-3	CREAMY	FX2 (ROTARY) SPEED SELECT	DISTORTION1 DELAY1	TUNER	FX2 (ROTARY)	PEDAL FX FX2 (ROTARY) EFFECT LEVEL
P39-4	SE MIX	DIV1 MODE	CHORUS	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P39-5	FAT COMP LEAD	DIV1 CH.SELECT	COMPRESSOR FX2 (PHASER)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P40-1	SPACED OUT	DELAY1 DELAY2	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P40-2	ELECTRIC SPANISH	AIRD PREAMP1 SOLO	REVERB EFFECT LEVEL	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P40-3	MAGIC CARPET	DISTORTION1	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P40-4	NOTHING 4 MONEY	DIV1 CH.SELECT	FX2 (HUMANIZER)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P40-5	ORGANIC FOOD	FX2 (ROTARY)	DELAY1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P41-1	5TH DIMENSION	FX2 (SLICER)	FX3 (HUMANIZER)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P41-2	CLASS-A HEAVEN	DISTORTION1	AIRD PREAMP1 SOLO	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P41-3	DREADLOCK CRUNCH	FX1 (PHASER) FX2 (TOUCH WAH)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P41-4	SURROUND GUITAR	FX1 (SLICER)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX



Patch #	Patch name	CTL1	CTL2	CTL3	EXP1 SW	EXP1
P41-5	IBIZA TRANCE GTR	FX1 (ROTARY) FX2 (PHASER) FX3 (SLICER)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P42-1	SOULFUL GAIN	DIV1 CH.SELECT	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P42-2	SOARING CLEANS	FX3 (VIBRATO)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P42-3	DANCING GUITAR	FX1 (PHASER) FX2 (VIBRATO) FX3 (SLICER)	MASTER DELAY TAP	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P42-4	70s BARRACUDA OD	FX1 (FLANGER)	DELAY2	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P42-5	STREREO SMACK	AIRD PREAMP1 SOLO AIRD PREAMP2 SOLO	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P43-1	WICKED STACK	AIRD PREAMP1 SOLO AIRD PREAMP2 SOLO	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P43-2	LIVE IN POMPEII	BPM TAP	FX3 (SLOW GEAR)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P43-3	SLIDE BAR	DISTORTION1 DISTORTION2	REVERB	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P43-4	CLEAR STREAM	DISTORTION1	FX1 (FLANGER) FX3 (FLANGER)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P43-5	PLAIN TOP BLUES	DISTORTION1	AIRD PREAMP1 SOLO AIRD PREAMP2 SOLO	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P44-1	SPACE ODYSSEY	DIV1 CH.SELECT	FX1 (CHORUS) CHORUS	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P44-2	COLD CUTS	FX1 (FLANGER)	FX2 (TREMOLO)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P44-3	TEXAS MOON	FX1 (ROTARY)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P44-4	NASHVILLE CRUNCH	AIRD PREAMP1 SOLO AIRD PREAMP2 SOLO	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P44-5	FLOYDISH CLEAN	BPM TAP	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P45-1	LESLIFIED	FX1 (ROTARY)	FX3 (ROTARY)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P45-2	SPLIT DECISION	DISTORTION1	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P45-3	COOL RUNNINGS	FX1 (SLICER)	FX3 (SLICER)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P45-4	10000\$ RACK	FX1 (CHORUS)	FX2 (ROTARY)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P45-5	SUPER BOOTH GTR	BPM TAP	FX3 (SLICER)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P46-1	THROATY AMBIENCE	BPM TAP	FX3 (HUMANIZER)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P46-2	BREAKING HEARTS	DISTORTION1	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P46-3	HEAVENS STEPS	MASTER DELAY	FX1 (PHASER)	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P46-4	HOW MANY?	CHORUS	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P46-5	VOLCANO	FX1 (PHASER)	DELAY2	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P47-1	QUEEN KILLER BEE	DISTORTION1	DELAY4	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P47-2	SWINGING SALTANA	DISTORTION1	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P47-3	MOON WALKING	FX1 (FLANGER) MASTER DELAY	COMPRESSOR	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P47-4	COMFORTABLY PINK	MASTER DELAY	AIRD PREAMP1 SOLO	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P47-5	SHONKY KEIFF	MASTER DELAY	DISTORTION1	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX

## Sound List

Patch #	Patch name	CTL1	CTL2	CTL3	EXP1 SW	EXP1
P48-1	CLEAN SHIMMER	DIV1 CH.SELECT	REVERB TIME	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P48-2	FOR AC-ELECTRIC	CHORUS	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P48-3	RASPING OUT	DIV1 CH.SELECT	FX3 (HUMANIZER)	TUNER	FX1 (RING MOD)	FX1 (RING MOD) FREQUENCY
P48-4	EASTERN VIBE	FX3 (VIBRATO)	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P48-5	DUB CUT	BPM TAP	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P49-1	ROOTSY COMBO	AIRD PREAMP1 SOLO	REVERB	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P49-2	DIRTY TWEED	AIRD PREAMP1 SOLO	REVERB	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P49-3	WARM CLEAN	COMPRESSOR	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P49-4	DUAL ECHO	MASTER DELAY	DELAY4	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P49-5	FUZZ OCTAVE	REVERB	MASTER DELAY	TUNER	PEDAL FX	FOOT VOLUME/PEDAL FX
P50-1	LOOPER CLEAN	LOOPER	LOOPER STOP	LOOPER CLEAR	PEDAL FX	FOOT VOLUME/PEDAL FX
P50-2	LOOPER CRUNCH	LOOPER	LOOPER STOP	LOOPER CLEAR	PEDAL FX	FOOT VOLUME/PEDAL FX
P50-3	LOOPER DRIVE	LOOPER	LOOPER STOP	LOOPER CLEAR	PEDAL FX	FOOT VOLUME/PEDAL FX
P50-4	LOOPER SOLO	LOOPER	LOOPER STOP	LOOPER CLEAR	PEDAL FX	FOOT VOLUME/PEDAL FX
P50-5	LOOPER -1OCT	LOOPER	LOOPER STOP	LOOPER CLEAR	PEDAL FX	FOOT VOLUME/PEDAL FX