

# JHS

3 SERIES

# FLANGER

The 3-Series Flanger is inspired by the classic analog flangers of the past.

---

## CONTROLS

**BLEND** - This control blends in the flanger effect over your clean signal. Turn knob right for increased flange and experiment with this knob in lower positions for “almost chorus” tones.

**RATE** - Controls the speed of the flange. Turning the knob clockwise increases the speed.

**INTENSITY** - Controls the amount of flange. Left is mild flanging, right is a more extreme flanging.

**TAPE** - Toggle up moves the sound into tape-like sweeps with zero through flanging. This mode is inspired by real tape flanging as done in studios by altering the speed of tape machines during playback.

## JACKS

**INPUT** - 1/4” jack on the right side of the pedal.

**OUTPUT** - 1/4” jack on the left side of the pedal.

**POWER** - Requires 9V DC negative center power and consumes 70mA. Do not use more than 9V DC. You will void your warranty.