



Thank you for your purchase of the **NAKED OD™** by Tone Freak Effects! The **NAKED OD™** is a lighter OverDrive. Placed in front of an already slightly or fully driven amp, the **NAKED OD™** can clean boost your tone as well as giving you even more "hair". With a clean amp, the **NAKED OD™** adds a nice crunch for chord and solo work.

CONTROLS

Drive: Increase the gain of the unit by turning the knob clockwise. Turning the knob counter clockwise will decrease the gain.

Tone: Turning the knob clockwise will increase the high-end tone. Counter clockwise will increase the low-end tone.

Level: To increase the output volume, turn the knob

clockwise. By turning the volume control counter clockwise, you will decrease the output volume.

3-Way Mini-Toggle: The **NAKED OD™** has 3 different clipping sections.

- **Right** position uses symmetrical clipping and has the most "amp-like" characteristic of the clipping variations. This position has the most gain and compression compared to the other two positions.
- **Left** position engages the asymmetrical clipping. You will find this position to have a higher output volume from the Right position, so adjust your Level control to compensate. Asymmetrical clipping produces a more "classic" quality compared to the other two positions.
- **Middle** position is also called the "diode lift" position. The Left and Right positions use diodes to clip the signal, but the Middle position doesn't have any diodes, so the resulting tone is more "open" than the other two positions. NOTE: The Middle position has the highest output volume, so be careful when engaging this position.

The **NAKED OD™** uses a 9V battery or a 2.1 mm center negative pin power adapter.